

www.yoshimura-rd.com

R-K5710-K 2010-2011 BMW S1000RR Timing Inspection Plug



NO.	DESCRIPTION	QTY	PART #
1	Timing Inspection Plug	1	R-K5710

Instructions:

- 1. Remove stock timing inspection plug.
- 2. Remove stock rubber o-ring from timing inspection plug and install on Yoshimura timing inspection plug.
- 3. Install Yoshimura timing inspection plug. Torque to 7.4 lb-ft (10 Nm).

If safety wire is required, loop safety wire through the holed drilled in the plug to optional case saver kit or to secure location.

197 YOSHIMURA

5420 DANIELS STREET STE A. CHINO CALIF. 91710 · (800)634-9166 · (909)628-4722 · FACSIMILE (909)591-2198

www.yoshimura-rd.com

R-K5710-K 2010-2011 BMW S1000RR Timing Inspection Plug



NO.	DESCRIPTION	QTY	PART #
1	Timing Inspection Plug	1	R-K5710

Instructions:

- 1. Remove stock timing inspection plug.
- 2. Remove stock rubber o-ring from timing inspection plug and install on Yoshimura timing inspection plug.
- 3. Install Yoshimura timing inspection plug. Torque to 7.4 lb-ft (10 Nm).

If safety wire is required, loop safety wire through the holed drilled in the plug to optional case saver kit or to secure location.

TENT YOSHIMURA

EL C CTDEET CTE A CHINIO CALLE 01710 . (900)/224 0100 . (000)/239 4723 . EACSIMILE (000)/201 2109

www.yoshimura-rd.com

R-K5710-K 2010-2011 BMW S1000RR Timing Inspection Plug



NO.	DESCRIPTION	QTY	PART #
1	Timing Inspection Plug	1	R-K5710

Instructions:

- 1. Remove stock timing inspection plug.
- 2. Remove stock rubber o-ring from timing inspection plug and install on Yoshimura timing inspection plug.
- 3. Install Yoshimura timing inspection plug. Torque to 7.4 lb-ft (10 Nm).

If safety wire is required, loop safety wire through the holed drilled in the plug to optional case saver kit or to secure location.

EDA YOSHIMURA

O DANIEL C CTREET CTE A CHINO CALIE 01710 . (900)624 0466 . (000)629 4722 . EACCIMILE (000)601 2109

www.yoshimura-rd.com

R-K5710-K 2010-2011 BMW S1000RR Timing Inspection Plug



NO.	DESCRIPTION	QTY	PART #
1	Timing Inspection Plug	1	R-K5710

Instructions:

- 1. Remove stock timing inspection plug.
- 2. Remove stock rubber o-ring from timing inspection plug and install on Yoshimura timing inspection plug.
- Install Yoshimura timing inspection plug. Torque to 7.4 lb-ft (10 Nm).

If safety wire is required, loop safety wire through the holed drilled in the plug to optional case saver kit or to secure location.